

FURUNO

OPERATOR'S MANUAL

MARINE DISPLAY

Model **MU-152**

(Product Name: MONITOR UNIT)

IMPORTANT NOTICES

General

- This manual has been authored with simplified grammar, to meet the needs of international users.
- The operator of this equipment must read and follow the descriptions in this manual. Wrong operation or maintenance can cancel the warranty or cause injury.
- Do not copy any part of this manual without written permission from FURUNO.
- If this manual is lost or worn, contact your dealer about replacement.
- The contents of this manual and equipment specifications can change without notice.
- The example screens (or illustrations) shown in this manual can be different from the screens you see on your display. The screens you see depend on your system configuration and equipment settings.
- Save this manual for future reference.
- Any modification of the equipment (including software) by persons not authorized by FURUNO will cancel the warranty.
- The following concern acts as our importer in Europe, as defined in DECISION No 768/2008/EC.
 - Name: FURUNO EUROPE B.V.
 - Address: Ridderhaven 19B, 2984 BT Ridderkerk, The Netherlands
- All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

How to discard this product

Discard this product according to local regulations for the disposal of industrial waste. For disposal in the USA, see the homepage of the Electronics Industries Alliance (<http://www.eiae.org/>) for the correct method of disposal.

How to discard a used battery

Some FURUNO products have a battery(ies). To see if your product has a battery, see the chapter on Maintenance. Follow the instructions below if a battery is used. Tape the + and - terminals of battery before disposal to prevent fire, heat generation caused by short circuit.


In the European Union

The crossed-out trash can symbol indicates that all types of batteries must not be discarded in standard trash, or at a trash site. Take the used batteries to a battery collection site according to your national legislation and the Batteries Directive 2006/66/EU.



In the USA

The Mobius loop symbol (three chasing arrows) indicates that Ni-Cd and lead-acid rechargeable batteries must be recycled. Take the used batteries to a battery collection site according to local laws.



In the other countries

There are no international standards for the battery recycle symbol. The number of symbols can increase when the other countries make their own recycle symbols in the future.



SAFETY INSTRUCTIONS

Read these safety instructions before you operate the equipment.

| | |
|--|---|
|  WARNING | Indicates a condition that can cause death or serious injury if not avoided. |
|  CAUTION | Indicates a condition that can cause minor or moderate injury if not avoided. |

| | | |
|--|--|--|
|  Warning, Caution |  Prohibitive Action |  Mandatory Action |
|--|--|--|

Safety Instructions for the Operator

| |
|---|
|  WARNING |
|  Immediately turn off the power at the switchboard if water leaks into the equipment or something is dropped into the equipment. Continued use of the equipment can cause fire or electrical shock. Contact your dealer. |
|  Immediately turn off the power at the switchboard if the equipment is emitting smoke or fire. Continued use of the equipment can cause fire or electrical shock. Contact your dealer. |
|  Turn off the power immediately if you feel the equipment is behaving abnormally. Turn off the power at the switchboard if the equipment becomes abnormally warm or is emitting odd noises. Contact your dealer. |

| |
|--|
|  WARNING |
|  Do not disassemble or modify the equipment. Fire, electrical shock or serious injury can result. |
|  Use the proper fuse. Use of a wrong fuse can cause fire or damage to the equipment. |

| |
|---|
|  CAUTION |
|  Do not connect/disconnect the signal cable while the power is turned on. The unit may be damaged. |
|  Handle the display carefully. Injury can result if the display breaks. |

Safety Instructions for the Installer

⚠ WARNING

! Turn off the power at the switchboard before beginning the installation.
Fire or electrical shock can result if the power is left on.

! Do not install the equipment where it may get wet from rain or water splash.
Water in the equipment can result in fire, electrical shock or damage to the equipment.

⚠ CAUTION

! Observe the following compass safe distances to prevent interference to a magnetic compass:

| | | |
|--------|------------------|------------------|
| | Standard compass | Steering compass |
| MU-152 | 0.65 m | 0.40 m |

! When lifting the monitor unit, hold it together with the hard cover.
Grasping by the hard cover alone may allow the monitor unit to fall, resulting in possible bodily injury or damage to the equipment.

About the TFT LCD

- The TFT LCD is constructed using the latest LCD techniques, and displays 99.99% of its pixels. The remaining 0.01% of the pixels may drop out or blink, however this is not an indication of malfunction.
- The MU-152 is non-bonding monitor unit, so the dew condensation may occur depending on the ambient temperature.

TABLE OF CONTENTS

| | |
|--|-------------|
| FOREWORD | v |
| SYSTEM CONFIGURATION | vi |
| EQUIPMENT LISTS | vii |
| 1. MOUNTING, WIRING | 1 |
| 1.1 Preparation | 1 |
| 1.2 Flush Mounting, Fixed at Rear (Standard) | 3 |
| 1.3 Flush Mounting, Fixed at Front (Option)..... | 5 |
| 1.4 Desktop Mounting (Option)..... | 6 |
| 1.5 Flush Mounting, Fixed at Rear, with Hood (Option) | 8 |
| 1.6 Desktop Mounting, with Hood (Option)..... | 10 |
| 1.7 Replacing the MU-151C with the MU-152 | 10 |
| 1.8 Wiring | 11 |
| 2. ADJUSTMENTS | 12 |
| 2.1 RGB/DVI Setting..... | 12 |
| 2.2 Video Composite Signal Setting | 14 |
| 2.3 The Menu Window Setting | 15 |
| 2.3.1 How to adjust the menu window | 15 |
| 2.3.2 How to change the signal name..... | 16 |
| 3. OPERATION | 17 |
| 3.1 Controls | 17 |
| 3.2 How to Turn the Power On/Off | 18 |
| 3.2.1 Turn the power on/off..... | 18 |
| 3.2.2 Lock the key operation | 18 |
| 3.3 How to Adjust the Display Brilliance | 19 |
| 3.4 How to Select the Source for Main Picture..... | 19 |
| 3.5 How to Display the PIP Window | 19 |
| 3.6 SYSTEM Menu..... | 20 |
| 3.6.1 How to set the auto dimmer | 20 |
| 3.6.2 How to adjust the brilliance from the external equipment | 21 |
| 3.6.3 How to clear the memory | 21 |
| 4. MAINTENANCE, TROUBLESHOOTING | 22 |
| 4.1 Maintenance | 22 |
| 4.2 Troubleshooting..... | 23 |
| APPENDIX1 ABBREVIATIONS | AP-1 |
| SPECIFICATIONS | SP-1 |
| INSTALLATION MATERIALS | A-1 |
| OUTLINE DRAWINGS | D-1 |
| INTERCONNECTION DIAGRAM | S-1 |

FOREWORD

A Word to the Owner of the MU-152

FURUNO Electric Company thanks you for purchasing the MU-152 15" Marine Display. We are confident you will discover why the FURUNO name has become synonymous with quality and reliability.

Since 1948, FURUNO Electric Company has enjoyed an enviable reputation for quality and reliability throughout the world. This dedication to excellence is furthered by our extensive global network of agents and dealers.

Your equipment is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless properly installed and maintained. Please carefully read and follow the operation, installation and maintenance procedures set forth in this manual.

We would appreciate feedback from you, the end-user, about whether we are achieving our purposes.

Thank you for considering and purchasing FURUNO.

Features

The main features of the MU-152 are as shown below.

- Selectable display format (RGB × 1 line, Digital × 2 lines, Composite × 3 lines).
- Main or remote display for various equipment. For the connectable equipment, see "Connectable equipment (Landscape orientation only)" on page vi.
- All glass, narrow frame design
- Display resolution of 1024 × 768 (XGA)
- Brightness of 400 cd/m²
- Automatic brilliance adjustment with the light sensor.
- Picture-in-picture function
- Power on/off automatically via DVI signal.

Program


| Program Name | Version | Date of Change |
|--------------|---------------|----------------|
| APR PROGRAM | 2651038-xx.xx | Jul. 2017 |

xx denotes minor modifications.

CE declaration

With regards to CE declarations, please refer to our website (www.furuno.com), for further information about RoHS conformity declarations.

SYSTEM CONFIGURATION



*1: The USB port is for the brilliance control signal from the external equipment. You can not connect a PC or other device.

Connectable equipment (Landscape orientation only)

| Equipment | Resolution | Signal |
|----------------------|------------|-------------------------|
| CH-250/250S | VGA | Analog RGB, via IF-8000 |
| CH-270 | VGA | Analog RGB, via IF-8000 |
| CH-300 | VGA | Analog RGB, via IF-8000 |
| CSH-5L/8L | XGA | Analog RGB |
| CSH-5L/8L MARK-2 | XGA | Analog RGB |
| CH-500/600 | XGA | DVI |
| FSV-35/35S | SXGA*3 | DVI |
| FCV-30 | XGA/SXGA*3 | Analog RGB |
| FCV-2100 | XGA/SXGA*3 | DVI |
| FCV-1900 | XGA/SXGA*3 | DVI |
| CI-38/68/88 | VGA | Analog RGB |
| FAR-15x3/15x8 series | XGA | DVI |
| FAR-1417/1427*2 | XGA/SXGA*3 | DVI |
| GD-300*2 | XGA | DVI |
| GD-700*2 | XGA/SXGA*3 | DVI |

*2: For Japan only

*3: For SXGA input, a circle may be displayed as an ellipse because the aspect ratio differs. See "[DISP MODE]**" on page 13. Also, it may be difficult to read small characters.

EQUIPMENT LISTS

Standard supply

| Name | Type | Code No. | Qty | Remarks |
|------------------------|------------|-------------|-------|---|
| Monitor Unit | MU-152 | - | 1 | |
| Installation Materials | CP26-02400 | 000-034-939 | 1 set | Contents of Installation Materials <ul style="list-style-type: none"> • Flush Mount Fixture 15 (CP26-01303, Code No.: 001-175-950) • CP26-02401* (Code No.: 001-497-440) • Cable Assembly (MJ-A3SPF0013A-035C, Code No.: 000-176-666-10) |
| Accessories | FP26-00800 | 000-034-940 | 1 set | Contents of Accessories <ul style="list-style-type: none"> • Hard Cover 15 (26-005-2111-1, Code No.: 100-351-261-10) |
| Spare Parts | SP66-00503 | 002-876-340 | 1 set | Contents of Spare Parts <ul style="list-style-type: none"> • Glass Tube Fuse (FGBO-A 125V 3A PBF, Code No.: 000-155-850-10) 3 pcs. |

*: See the Installation materials at the back of this manual.

Optional supply

| Name | Type | Code No. | Qty | Remarks |
|----------------------------|--------------------|---|-------|--|
| Cable Assembly | 3COX-2P-6C 5M | 001-077-230-10 | 1 | Cable length: 5 m (15 pin D-sub connector at both ends) |
| | 3COX-2P-6C 10M | 001-077-220-10 | 1 | Cable length: 10 m (15 pin D-sub connector at both ends) |
| | DVI-D/D S-LINK 5M | 001-132-960-10 | 1 | Cable length: 5 m (with DVI-D connector at both ends) |
| | DVI-D/D S-LINK 10M | 001-133-980-10 | 1 | Cable length: 10 m (with DVI-D connector at both ends) |
| Bracket Assembly (w/knobs) | OP26-35 | 000-034-941 | 1 set | |
| Hood Assembly | OP26-3 | 001-080-840 | 1 set | |
| Flush Mount Kit | OP26-36 | 001-497-450 | 1 set | |
| Accessories | FP26-00401 | 001-175-940 | 1 | LCD Cleaning Cloth (19-028-3125-6, Code No.: 100-360-676-10) |
| Flush Mounting Template | C42-00903-B | 000-172-218-11 | 1 | For flush mounting, fixed at rear |
| Operator's Manual | OMJ-44970 | 000-194-292-1x (x denotes minor modifications.) | 1 | Japanese version |

1. MOUNTING, WIRING

1.1 Preparation

Mounting type

You can install the monitor unit as follows. See the outline drawings at the back of this manual for mounting dimensions.

- Flush mounting, fixed at rear (standard)
- Flush mounting, fixed at front (option)
- Desktop mounting (option)
- Flush mounting, fixed at rear, with hood (option)
- Desktop mounting, with hood (option)

Note 1: The face of the LCD monitor is made of glass. Handle it with care.

Note 2: For flush mounting, the mounting surface must be flat. Do not install the unit on an uneven surface. Also, take care that the monitor unit does not fall during the installation.

Mounting location

When you select a mounting location, remember the following points:

- Make sure the mounting location is strong enough to support the weight of the unit. See the outline drawings at the back of this manual.
- Locate the unit away from direct sunlight. An LCD may black out or condensation may occur if the LCD is exposed to direct sunlight for a long time.
- Select a location where the display can be easily viewed and the controls can be easily operated.
- Leave enough space around the unit for service and maintenance. See the outline drawings at the back of this manual for minimum service clearance.
- Locate the unit away from areas subject to water splash and rain. This monitor unit is for indoor.
- Observe the compass safe distances (see page iii) to prevent interference to a magnetic compass.

Included items

- | | |
|--------------------------------------|---------------------------------------|
| • Monitor Unit | • Cable Assembly (1 pc.) |
| • Flush Mount Fixture 15 (2 pcs.) | • Hard Cover 15 (1 pc.) |
| • Flush Mounting Sponge H15 (2 pcs.) | • Glass Tube Fuse (3 pcs.) |
| • Flush Mounting Sponge V15 (2 pcs.) | • Operator's Manual (1 pc.) |
| • Washer Head Screw (6 pcs.) | • Material Data Sheet (C-RoHS, 1 pc.) |
| • Cable Tie (4 pcs.) | |

1. MOUNTING, WIRING


Required tools

The following tools should be prepared in advance for this installation.

- Electrical drill, Hole saw: $\phi 18$ mm, for making the mounting holes
- Jig saw, File: For making the mounting holes
- Phillips-head screw driver: #2, for securing the flush mount fixtures
- Cable tie: For securing the cables

How to remove/attach the hard cover


Before you install this monitor unit, remove the hard cover as follows.



| |
|--|
| ⚠ CAUTION |
| ⚠ When lifting the monitor unit, hold it together with the hard cover. |
| Grasping by the hard cover alone may allow the monitor unit to fall, resulting in possible bodily injury or damage to the equipment. |

How to remove the hard cover

To attach the hard cover, follow the illustration in the figure below.



How to attach the hard cover


Cable connection

Before you install the monitor unit, run and connect all cables you use. See the interconnection diagram at the back of this manual.


1.2 Flush Mounting, Fixed at Rear (Standard)

This is the standard installation method.

1. Make a cutout in the mounting location referring to the outline drawing at the back of this manual.
2. Attach the flush mounting sponges H15 and V15 in the order shown in the figure below.




3. Connect all cables at the back of the monitor unit. See section 1.8.
4. Fit the monitor unit to the cutout.




1. MOUNTING, WIRING


5. Screw the wing bolts and the wing nuts of the flush mount fixture 15 so that the protector moves to the mount fixture.



6. Fasten the flush mount fixture 15 to the right and left sides of the rear of the monitor unit with the washer head screws (6 places).




7. Fasten the wing bolts, in the numerical order shown in the figure below so that the protectors touch the mounting panel.



8. Fasten the wing bolts tightly, in the numerical order shown in step 7.

- Fasten the wing nuts tightly.




1.3 Flush Mounting, Fixed at Front (Option)

If you do not have the enough space to fix the monitor unit from the rear, you can fix it from the front with the flush mount kit OP26-36 (option).

Flush Mount Kit OP26-36 (Code No.: 001-497-450)


| Name | Type | Code No. | Qty. |
|---------------------------|-------------|----------------|------|
| Flush Mounting Panel (15) | OP26-36-1 | 001-497-520 | 1 |
| Washer Head Screw | M4×10 | 000-163-836-10 | 8 |
| Self Tapping Screw | 5×20 | 000-162-609-10 | 4 |
| Flush Mounting Template | C42-00909-B | 000-172-636-11 | 1 |

- Make a cutout in the mounting location with the flush mounting template (included).
- Attach the flush mounting sponges H15 and V15 in the order shown in the figure below.




1. MOUNTING, WIRING

- Attach the flush mounting panel (15) to the monitor unit from the rear with the washer head screws (M4×10, 8 places, torque: 1.2 N•m). Do not confuse the top and bottom of the panel and check that screw holes on the panel and unit are aligned.



- Connect all cables at the back of the monitor unit. See section 1.8.
- Fit the monitor unit assembly to the cutout.
- Secure the monitor unit to the cutout with the self tapping screws (4 places).




1.4 Desktop Mounting (Option)

You can mount the monitor unit on a desktop, using the bracket assembly OP26-35 (option).


Bracket Assembly OP26-35 (Code No.: 000-034-941)

| Name | Type | Code No. | Qty. |
|-------------------------|-----------|----------------|------|
| Mounting Bracket (15) | OP26-2-1 | 001-080-820 | 1 |
| Bracket Support w/knobs | OP26-35-1 | 001-497-480 | |
| Self-Tapping Screw | 5×20 | 000-162-608-10 | 4 |
| Binding Head Screw | M4×10 | 000-172-165-10 | 6 |


1. Loosen the knobs of the bracket support to separate the mounting bracket (15) from the bracket support.



2. Secure the mounting bracket (15) to the mounting location with four self-tapping screws.




3. Attach the bracket support to the rear of the monitor unit with the binding head screws (M4×10, 6 places, torque: 1.2 N·m).



1. MOUNTING, WIRING

4. Connect all cables at the back of the monitor unit. See section 1.8.
5. Loosen the knobs of the bracket support and set them in the notches on the mounting bracket (15).



6. Adjust the angle of the monitor unit and fasten the knobs tightly.


1.5 Flush Mounting, Fixed at Rear, with Hood (Option)

You can attach a hood when flush mounting the unit from the rear, using the hood assembly OP26-3 (option).


Hood Assembly OP26-3 (Code No.: 001-080-840)

| Name | Type | Code No. | Qty. |
|------------------------------|---------------|----------------|------|
| Hood (15) Assembly | OP26-3-1 | 001-080-950 | 1 |
| Hood Fixing Plate 15 | 26-005-2302-1 | 100-351-321-10 | 2 |
| F-Mount Hood Packing 15 | 26-005-2305 | 100-351-710-10 | 1 |
| Hood Packing Bottom 15 | 26-005-2306 | 100-351-720-10 | 1 |
| F-Mount Hood Packing Side 15 | 26-005-2307 | 100-351-730-10 | 2 |
| Knob M4 | 03-163-2303-2 | 100-343-602-10 | 4 |
| Flat Head Screw | M3×8 | 000-172-167-10 | 6 |
| Flush Mounting Template | C42-00908-B | 000-172-635-11 | 1 |


1. Make a cutout in the mounting location with the flush mounting template (included).
2. Attach the hood fixing plates 15 to the right and left of the monitor unit with flat head screws (M3×8, 6 places, torque: 0.6 N·m).



3. Attach the F-mount hood packing 15 to the top brim, the hood packing bottom 15 to the bottom brim, and then attach the F-mount hood packing side 15 to the right and left sides of the monitor unit from the rear side as shown the figure below.




4. Follow steps 3 to 9 in section 1.2 to fit the monitor unit to the mounting location.
5. Loosely fix the knobs M4 (4 pcs.) to the hood fixing plates 15.
6. Slide the cutouts of the hood (15) assembly onto the knobs M4.



1. MOUNTING, WIRING

7. Press the top of the hood (15) assembly to fit the knobs M4 in the cutouts.



8. Fasten the knobs (4 places) to secure the hood (15) assembly in place.

1.6 Desktop Mounting, with Hood (Option)

You can attach a hood when desktop mounting the unit, using the hood assembly OP26-3 (option) and the bracket assembly OP26-35 (option). See sections 1.4 and 1.5.

1. Follow steps 1 to 3 in section 1.4.
2. Follow steps 1 to 8 in section 1.5.
3. Follow steps 5 and 6 in section 1.4.

1.7 Replacing the MU-151C with the MU-152

There are two methods to replace an existing flush mounted MU-151C with the MU-152; fixed from the front (requires the flush mount kit, available as an optional extra), or fixed from the rear. We recommend the flush mounting fixed at front to hide the screw holes.

Fixing from the front

1. Use the flush mounting template (included with the optional kit) to broaden the cutout at the mounting location.
2. Follow steps 2 to 6 in section 1.3.


Fixing from the rear

1. Referring to the outline drawing at the back of this manual, broaden the cutout at the mounting location.
2. Follow steps 2 to 9 in section 1.2.

1.8 Wiring

Refer to the figure below and the interconnection diagram at the back of this manual to connect cables.


Connector



How to secure composite signal cable

Secure composite cables with cable ties at the cable clamps, to prevent disconnection.

1. Pass the cable tie (supplied) through the side of the cable clamp.
2. Set the cable in the cable tie and fasten the cable tie.
3. Cut off excess cable tie with nippers.



2. ADJUSTMENTS

Adjust the MU-152 according to the equipment connected.

2.1 RGB/DVI Setting

You can adjust the settings for the RGB, DVI-D1 and DVI-D2 ports individually. Turn on the external equipment and adjust the monitor unit as follows.

1. Select the signal to adjust at the DISP selection window. See section 3.4.
 - 1) Press the **DISP** key.
 - 2) Press the **▲** or **▼** key to select [RGB], [DVI1] or [DVI2].
2. Press the **MENU** key to show the menu. The menu closes automatically when there is no operation for one minute.
3. Press the **◀** or **▶** key to select [RGB], [DVI1] or [DVI2]. The current selection (the cursor) is shown in orange. The displayed menu items depend on the selected menu. The [DVI1] and [DVI2] menus show the same menu items.

Note: If there is no signal, menu items appear in gray and are not available.

| RGB | DVI1 | DVI2 | VIDEO1 | VIDEO2 | VIDEO3 | OSD | SYSTEM |
|-------------|------|------|-----------|---------------------------|--------|-----|--------|
| H_SIZE | | | 640 | | | | |
| V_SIZE | | | 480 | | | | |
| PHASE | | | 16 (1~32) | | | | |
| CONTRAST | | | 32 (1~64) | | | | |
| H_POSITION | | | 50 (1~99) | | | | |
| V_POSITION | | | 20 (1~40) | | | | |
| R_LEVEL | | | 31 (1~64) | | | | |
| G_LEVEL | | | 31 (1~64) | | | | |
| B_LEVEL | | | 31 (1~64) | | | | |
| TEMPERATURE | | | 7000K | (5500K/6500K/7000K/8000K) | | | |
| B_STRETCH | | | OFF | (OFF, 1~10) | | | |
| W_STRETCH | | | OFF | (OFF, 1~10) | | | |
| DISP MODE | | | FULL | (FULL/NORMAL) | | | |
| SHARPNESS | | | 5 | (1~10) | | | |

[RGB] setting menu

| RGB | DVI1 | DVI2 | VIDEO1 | VIDEO2 | VIDEO3 | OSD | SYSTEM |
|-----|-------------|------|-----------|---------------------------|--------|-----|--------|
| | CONTRAST | | 32 (1~64) | | | | |
| | H_POSITION | | 25 (1~50) | | | | |
| | V_POSITION | | 20 (1~40) | | | | |
| | R_LEVEL | | 31 (1~64) | | | | |
| | G_LEVEL | | 31 (1~64) | | | | |
| | B_LEVEL | | 31 (1~64) | | | | |
| | TEMPERATURE | | 7000K | (5500K/6500K/7000K/8000K) | | | |
| | B_STRETCH | | OFF | (OFF, 1~10) | | | |
| | W_STRETCH | | OFF | (OFF, 1~10) | | | |
| | DISP MODE | | FULL | (FULL/NORMAL) | | | |
| | SHARPNESS | | 1 | (1~10) | | | |

[DVI1/2] setting menu

4. Press the **▲** or **▼** key to select the menu item to adjust.
5. Press the **◀** or **▶** key to adjust the setting.
6. Press the **MENU** key to close the menu.

[RGB], [DVI1/2] menu descriptions

| Menu item | Function | Setting |
|--------------------------------|---|--|
| [H_SIZE] (Only for [RGB] menu) | Adjusts the image size horizontally. Horizontal size: ◀ (narrow), ▶ (wide) | Depending on input signal |
| [V_SIZE] (Only for [RGB] menu) | Adjusts the image size vertically. Vertical size: ◀ (narrow), ▶ (wide) | |
| [PHASE]* (Only for [RGB] menu) | Adjusts the sample timing so that screen flicker disappears and the text is clear. | 1 to 32 |
| [CONTRAST] | Adjusts the contrast level. ◀ (darken), ▶ (brighten) | 1 to 64 |
| [H_POSITION] | Moves the image position horizontally. ◀ (leftward), ▶ (rightward) | 1 to 99 ([RGB]), 1 to 50 ([DVI1], [DVI2]) |
| [V_POSITION] | Moves the image position vertically. ◀ (upward), ▶ (downward) | 1 to 40 |
| [R_LEVEL] | Adjusts the red color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [G_LEVEL] | Adjusts the green color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [B_LEVEL] | Adjusts the blue color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [TEMPERATURE] | Adjusts the color temperature. [5500K] (the most reddish), [8000K] (the most bluish) | 5500K, 6500K, 7000K, 8000K |
| [B STRETCH] | Emphasizes the black color. [OFF] (standard), ◀ (weaken), ▶ (strengthen) | [OFF], 1 to 10 |
| [W STRETCH] | Emphasizes the white color. [OFF] (standard), ◀ (weaken), ▶ (strengthen) | [OFF], 1 to 10 |
| [DISP MODE]** | Selects the display method. [FULL]: Shows the input signal on entire screen. [NORMAL]: Shows the input signal with original aspect ratio. | [FULL], [NORMAL] |
| [SHARPNESS]* | Sharpens the edge horizontally. ◀ (soften characters and lines), ▶ (sharpens characters and lines) | 1 to 10 |

*: If the characters are not clear, adjust [PHASE] and [SHARPNESS].

** : For SXGA input, a circle may be displayed as an ellipse because the aspect ratio differs. In this case, set [DISP MODE] to [NORMAL]. The right and left edges of the screen are left blank, but this is normal.

2.2 Video Composite Signal Setting

You can adjust the VIDEO1, 2 or 3 signal from the VIDEO1, VIDEO2 and VIDEO3 ports separately. The VIDEO1, 2 or 3 signal is also displayed in the PIP window (see section 3.5).

1. Select the signal to adjust at the DISP selection window (see section 3.4).
2. Press the **MENU** key to show the menu.
3. Press the ◀ or ▶ key to select [VIDEO1], [VIDEO2] or [VIDEO3]. The [VIDEO1], [VIDEO2] and [VIDEO3] menus show the same menu items.

| RGB | DV11 | DV12 | VIDEO1 | VIDEO2 | VIDEO3 | OSD | SYSTEM |
|-------------|------|-------|--------|---------------------------|--------|-----|--------|
| PIP_SIZE | | | 5 | (1~10) | | | |
| CONTRAST | | | 32 | (1~64) | | | |
| R_LEVEL | | | 31 | (1~64) | | | |
| G_LEVEL | | | 31 | (1~64) | | | |
| B_LEVEL | | | 31 | (1~64) | | | |
| TEMPERATURE | | 7000K | | (5500K/6500K/7000K/8000K) | | | |
| B STRETCH | | | OFF | (OFF, 1~10) | | | |
| W STRETCH | | | OFF | (OFF, 1~10) | | | |

4. Press the ▲ or ▼ key to select the menu item to adjust.
5. Press the ◀ or ▶ key to adjust the setting.
6. Press the **MENU** key to close the menu.

[VIDEO1/2/3] menu descriptions


| Menu item | Function | Setting |
|---------------|--|---------------------------------------|
| [PIP_SIZE] | Adjusts the size of the picture-in-picture window. Note: This setting is available when the PIP window is displayed. | 1 (47 mm×31 mm) to 10 (235 mm×160 mm) |
| [CONTRAST] | Adjusts the contrast level. ◀ (darken), ▶ (brighten) | 1 to 64 |
| [R_LEVEL] | Adjusts the red color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [G_LEVEL] | Adjusts the green color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [B_LEVEL] | Adjusts the blue color level. ◀ (weaken), ▶ (strengthen) | 1 to 64 |
| [TEMPERATURE] | Adjusts the color temperature. [5500K] (the most reddish), [8000K] (the most bluish) | 5500K, 6500K, 7000K, 8000K |
| [B STRETCH] | Emphasizes the black color. [OFF] (standard), ◀ (weaken), ▶ (strengthen) | [OFF], 1 to 10 |
| [W STRETCH] | Emphasizes the white color. [OFF] (standard), ◀ (weaken), ▶ (strengthen) | [OFF], 1 to 10 |

2.3 The Menu Window Setting

2.3.1 How to adjust the menu window

You can adjust the position and transparency of the menu window on the [OSD] (On Screen Display) menu.

1. Press the **MENU** key to show the menu.
2. Press the ◀ or ▶ key to select [OSD].



3. Press the ▲ or ▼ key to select the menu item to adjust.
4. Press the ◀ or ▶ key to adjust the setting.
5. Press the **MENU** key to close the menu.

[OSD] menu descriptions


| Menu item | Function | Setting |
|---------------|---|-------------------------|
| [H_POSITION] | Moves the menu window horizontally. ◀ (leftward), ▶ (rightward) | 1 to 29 |
| [V_POSITION] | Moves the menu window vertically. ◀ (upward), ▶ (downward) | 1 to 37 |
| [TRANSLUCENT] | Adjusts the transparency of the background color (blue) on the menu window. [OFF]: Blue, [ON]: Translucent Note: Alpha blending technology is used for transparency effects. | [OFF], [ON] |
| [PIP SW TIME] | Switches the screen image on the PIP window among VIDEO1, VIDEO2 and VIDEO3 at the interval (5 to 20 seconds) selected here. When [OFF] is selected, this function is not available. | [OFF], 5 to 20 |
| [PIP SKIP] | Selects which video signals to skip in the PIP window when [PIP SW TIME] is active. [OFF]: VIDEO1, VIDEO2 and VIDEO3 are shown in turn. [V1]: VIDEO1 is skipped. VIDEO2 and VIDEO3 are shown alternately. [V2]: VIDEO2 is skipped. VIDEO1 and VIDEO3 are shown alternately. [V3]: VIDEO3 is skipped. VIDEO1 and VIDEO2 are shown alternately. | [OFF], [V1], [V2], [V3] |
| [CUSTOM NAME] | See section 2.3.2. | |

2. ADJUSTMENTS


2.3.2 How to change the signal name

You can change the signal name ([RGB], [DVI1/2] or [VIDEO1/2/3]) to a name which is easier to understand, such as the name of the connected equipment. The changed name is shown in the DISP selection window, PIP selection window and the indication shown at the upper right of the screen. See sections 3.4 and 3.5.


1. Press the **MENU** key to show the menu.
2. Press the ◀ or ▶ key to select [OSD].
3. Press the ▼ key to select the signal whose name you want to change. In the example below, [RGB] is selected.



4. Press the ▶ key to select the character to change. In the example below, [G] of RGB is selected.




5. Press the ▲ or ▼ key to select an appropriate alphanumeric character. In the example below, [5] is selected. You can set up to ten characters. "A to Z", "0 to 9", "-", ".", " " (space) are available.



6. To change another signal name, press the ◀ key several times to return the cursor to the signal name area. Repeat steps 3 to 5.
7. Press the **MENU** key to close the menu.

3. OPERATION

3.1 Controls



3.2 How to Turn the Power On/Off

This section shows how to turn on/off the monitor unit and the key lock function.

3.2.1 Turn the power on/off

How to turn on/off the power depends on the setting of the slide switch. The slide switch is set when the monitor unit is installed. See section 1.8.

Note 1: When you restart the monitor unit, wait at least three seconds before powering the unit.

Note 2: The screen refreshes slower in low ambient temperatures.

Slide switch “ON”

The external equipment connected to the DVI port (DVI-D1 or DVI-D2) can power on/off the monitor unit. See the external equipment’s operator’s manual.

Note 1: You can not turn on the power with the /BRILL key on the MU-152.

Note 2: When you connect the cables to both DVI-D1 and DVI-D2 ports, turn off the power of both connected equipment to turn off the monitor unit.

Note 3: When turning off the power with long press of the /BRILL key on the MU-152, do the following procedures to restart the MU-152.

- 1) Restart the equipment connected to the DVI-D1 or DVI-D2 port.
- 2) Disconnect the power cable from the MU-152, then connect it again.

Slide switch “OFF”

1. Press the /BRILL key to turn on the monitor unit.
2. Press and hold the /BRILL key for three seconds to turn off the monitor unit. While you hold the key, the indication shown in the figure to the right appears.



SHUT DOWN
This monitor will shut down in three seconds.

3.2.2 Lock the key operation

You can lock the monitor unit to prevent operation. Any key (except the /BRILL key) will be inoperative.

1. While you hold the **PIP** key, turn on the monitor unit. Keep the **PIP** key pressed for more than five seconds.

Note: When the slide switch is ON, turn on the connected external equipment while pressing the **PIP** key to turn on the monitor unit.

2. To cancel the lock, turn off the monitor unit and then turn it on while you hold the **PIP** key. Keep the **PIP** key pressed for more than five seconds.


Note: The menu is not displayed when the monitor unit is locked. All menu settings retain their value from before the monitor unit is locked.

3.3 How to Adjust the Display Brilliance

You can adjust the display brilliance as follows:

Note: This function is available when [AUTO DIMMER] and [EXT BRILL CTRL] on the [SYSTEM] menu are set to [OFF]. See section 3.6.1.

1. Press the /BRILL key momentarily to show the BRILL adjustment window. The window closes automatically when there is no operation for five seconds.
2. Press the ◀ or ▶ key to adjust the brilliance. You can also adjust the brilliance by pressing the /BRILL key repeatedly. The setting range is 1 to 50 (default: 50).
3. Press the ▲ or ▼ key to close the window.



Note 1: If you turn off the monitor unit with the minimum brilliance, it may be difficult to see the screen when you next turn the power on, due to ambient light. In this case, press the /BRILL key repeatedly.

Note 2: When connecting the MU-152 to the FAR-15x3/15x8, FAR-1417/1427 or FCV-1900, you can adjust the display brilliance from the equipment's control unit. See section 3.6.2.

3.4 How to Select the Source for Main Picture


Select the signal to display on the entire screen as follows:

1. Press the **DISP** key to show the DISP selection window. The signal names are shown as customized at section 2.3.2 on the window. The window closes automatically when there is no operation for five seconds.
2. Press the ▲ or ▼ key to select a signal. You can also select the signal by pressing the **DISP** key continuously.
 - [RGB]: The signal from the RGB port is displayed.
 - [DVI1], [DVI2]: The signal from the selected DVI port is displayed.
 - [VIDEO1] to [VIDEO3]: The external video from the selected VIDEO port is displayed.
3. Press the ◀ or ▶ key to close the window. The name of the selected signal appears at the top right of the screen for five seconds after the DISP selection window disappears. If there is no signal, "NO SIGNAL" appears.



3.5 How to Display the PIP Window

The PIP (picture-in-picture) window, which displays the picture input to the VIDEO port, is available on the RGB, DVI1 and DVI2 displays.



3. OPERATION

1. When the RGB, DVI1 or DVI2 display appears, press the **PIP** key to show the PIP selection window. The signal names appear with their customized name (see section 2.3.2). The window closes automatically when there is no operation for five seconds.
2. Press the ▲ or ▼ key to select the VIDEO port required. [VIDEO1] (2 or 3) can also be selected by pressing the **PIP** key continuously. When you select the [VIDEO1], [VIDEO2] or [VIDEO3], the PIP window is displayed. To close the PIP window, select [OFF].
3. Press the ◀ or ▶ key to close the PIP selection window.
4. You can move the PIP window by pressing the arrow keys when the menu is closed. Press and hold the arrow keys to move the PIP window quickly.



Note 1: To show the VIDEO1, VIDEO2 and VIDEO3 pictures alternately, set the cycle time (5 to 20 sec) with [PIP SW TIME] on the [OSD] menu. In this case, the above setting is invalid. See section 2.3.1.

Note 2: You can adjust the size of the PIP window on the [VIDEO1] (2 or 3) menu(s). See section 2.2.

3.6 SYSTEM Menu

You can set the brilliance control and clear the memory on the [SYSTEM] menu. Also, you can check signal status, the program number and the elapsed time (total time since first use) on the [SYSTEM] menu.

3.6.1 How to set the auto dimmer

The auto dimmer feature automatically adjusts the brilliance according to the ambient brightness detected by the light sensor on the front panel. Also, you can select the intervals at which the brilliance is adjusted.

Note: Do not put any objects in front of the light sensor.

1. Press the **MENU** key to show the menu.
2. Press the ▶ key to select [SYSTEM]. The message “Input Signal Searching Please Wait” is displayed and then the [SYSTEM] menu shown in the figure below is displayed.



3. Press the ▼ key to select [AUTO DIMMER].
4. Press the ◀ or ▶ key to select the adjustment interval.
 - [OFF]: Disable this function.
 - [1]: Every two seconds
 - [2]: Every 30 seconds
 - [3]: Every minute
 - [4]: Every three minutes
 - [5]: Every five minutes
5. Press the **MENU** key to close the menu.

3.6.2 How to adjust the brilliance from the external equipment

When the FAR-15x3/15x8 is connected to the DVI-D1 or DVI-D2 port, or the FAR-1417/1427 or FCV-1900 is connected to the USB port, you can adjust the display brilliance from the connected equipment.

Note 1: This function is available when [AUTO DIMMER] on the [SYSTEM] menu is set to [OFF].

Note 2: The FAR-1417/1427 is for Japan only.

1. Press the **MENU** key to show the menu.
2. Press the **▶** key to select [SYSTEM].
3. Press the **▼** key to select [EXT BRILL CTRL].
4. Press the **◀** or **▶** key to set the desired input item.

[OFF]: You can not adjust the brilliance from the external equipment.

[DVI1]: When the DVI1 is displayed, the brilliance signal from DVI-D1 port controls this display's brilliance. The **⏻/BRILL** key is available for screens other than the screen input from DVI1.

[DVI2]: When the DVI2 is displayed, the brilliance signal from DVI-D2 port controls this display's brilliance. The **⏻/BRILL** key is available for screens other than the screen input from DVI2.

[USB]: The brilliance signal from USB port controls this display's brilliance. The **⏻/BRILL** key is not available.

5. Press the **MENU** key to close the menu.

3.6.3 How to clear the memory

You can clear the memory to restore the default settings.

1. Press the **MENU** key to show the menu.
2. Press the **▶** key to select [SYSTEM].
3. Press the **▼** key to select [DEFAULT RESET].
4. Press the **▶** key. The indication changes from [NO] to [YES].



Note: To cancel, press the **◀** key. The indication changes from [YES] to [NO].

5. Press the **▶** key to select [reset].

4. MAINTENANCE, TROUBLESHOOTING

NOTICE

Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.

Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

4.1 Maintenance

Routine maintenance

Regular maintenance is important for good performance. Check the following on a regular basis to keep the equipment in good condition.

- Check that the connectors at the bottom of the monitor unit are tightly fastened.
- Check the ground wire and ground terminal for rust. Clean if necessary. Confirm that the ground wire is tightly fastened.
- Remove dust and dirt from the monitor unit with a dry, soft cloth. Do not use chemical cleaners to clean any part of the monitor unit. They can remove paint and markings.
- Check the dust or dirt is not on the display. Wipe it carefully to prevent scratching. For difficult to remove dirt or salt deposits, use a cloth made wet with water and neutral detergent (less than 1% detergent). Squeeze the cloth dry then clean the display. When the display is clean, gently wipe the display with a clean, soft, dry cloth, to prevent scratching.

Fuse replacement

The fuse in the fuse holder on the power cable protects the equipment from overvoltage and overcurrent. If the fuse blows, find the cause before you replace it. If the fuse blows again after replacement, contact your dealer.

WARNING

Use the proper fuse.

Use of a wrong fuse can cause fire or damage to the equipment.

| Name | Type | Code No. |
|------|--------------------|----------------|
| Fuse | FGBO-A 125V 3A PBF | 000-155-850-10 |

LCD replacement


The life of the LCD is approximately 100,000 hours. The actual numbers of hours depends on ambient temperature and humidity. When the brilliance cannot be raised sufficiently, contact your dealer to request replacement of the LCD.

Fan replacement

The life of the fan is approximately 95,000 hours. The actual numbers of hours depends on ambient temperature. When the fan cannot be rotated sufficiently, the message "FAN ERROR" is shown for 10 seconds after approx. 30 seconds from power-on. Turn off the power and contact your dealer to request replacement of the fan.

Note: When replacing the fan, check the mounting direction of fan referring to the figure below (rear inside view).

| Name | Type | Code No. |
|--------------------|--------------|----------------|
| Fan Motor Assembly | 109P0512H728 | 000-194-365-10 |



Fix the fan so that the label on the fan is directed downward, that is to the screen side.

4.2 Troubleshooting

See the following table to find the possible causes and the actions to restore normal operation. If repair of the equipment is necessary, contact your dealer and report the result of the troubleshooting to the serviceman.

Troubleshooting

| Case | Remedy |
|--|--|
| You can not turn on the power. | <ul style="list-style-type: none"> • Check the setting for the slide switch. See section 1.8. • Check the battery voltage with a multimeter. • Check the fuse on the power cable. • Fasten the power cable tightly. |
| You can not turn off the power. | <ul style="list-style-type: none"> • Press and hold the /BRILL key for eight seconds. • When the slide switch is set to ON, turn off the connected external equipment. |
| No picture | <ul style="list-style-type: none"> • Fasten the cables tightly. • Check the input signal. See section 3.6. • Check the setting for DISP selection window. See section 3.4. • Check if the display brilliance is not set to minimum. |
| You can not operate any key except the  /BRILL key. | Cancel the key lock function. See paragraph 3.2.2. |
| The small rectangular frame in black is displayed on the screen. | Press the PIP key then select [OFF]. |

APPENDIX 1 ABBREVIATIONS

| | Abbreviation | Meaning |
|---|--------------|---|
| A | APR | Application Program |
| | AUTO | Automatic |
| B | B | Black |
| | BRILL | Brilliance |
| C | CCD | Charge-Coupled Device |
| | CH | Type of FURUNO searchlight sonar |
| | CI | Type of FURUNO current indicator |
| | CSH | Type of FURUNO color scanning sonar |
| | CTRL | Control |
| D | DISP | Display |
| | DVD | Digital Versatile Disc |
| | DVI | Digital Visual Interface |
| E | EXT | External |
| F | FAR | Type of FURUNO radar |
| | FCV | Type of FURUNO fish finder |
| | Fh | Horizontal Frequency |
| | FSV | Type of FURUNO color scanning sonar |
| | Fv | Vertical Frequency |
| G | GD | Type of FURUNO color video plotter |
| H | H | Horizontal |
| L | LCD | Liquid Crystal Display |
| | LED | Light-Emitting Diode |
| N | NO. | Number |
| | NTSC | National Television System Committee |
| O | OSD | On-Screen Display |
| P | PAL | Phase Alternating Line |
| | PC | Personal Computer |
| | PIP | Picture-in-Picture |
| Q | Qty | Quantity |
| R | RGB | Red/Green/Blue |
| S | SW | Switch |
| | SXGA | Super Extended Graphics Array (1280×1024) |
| U | USB | Universal Serial Bus |
| V | V | Vertical |
| | VGA | Video Graphics Array (640×480) |
| W | W | White |
| X | XGA | Extended Graphics Array (1024×768) |

Units of measurement

| Abbreviation | Meaning | Abbreviation | Meaning |
|--------------|---------------|--------------|---------------|
| A | Ampere(s) | mm | Millimeter(s) |
| Hz | Hertz(es) | pc. | Piece |
| K | Kelvin | pcs. | Pieces |
| kHz | Kilohertz(es) | V | Volt(s) |
| m | Meter(s) | | |

SPECIFICATIONS OF MONITOR UNIT MU-152

1 GENERAL

| | | |
|-----|------------------|---|
| 1.1 | Screen type | 15-inch color LCD, 1024 x 768 (XGA) |
| 1.2 | Effective area | 304 x 228 mm approx. |
| 1.3 | Pixel pitch | 0.297 mm (Horizon/Vertical) |
| 1.4 | Brightness | 400 cd/m ² typical |
| 1.5 | Contrast | 900: 1 |
| 1.6 | View angle | 80° or more (left/right and up/down) |
| 1.7 | Visible distance | 1.02 m nominal |
| 1.8 | Input signal | |
| | RGB analog | 1 port, Non-interlace, RGB signal: 0.7 Vp-p, Sync. signal: TTL level |
| | DVI-D | 2 port, DVI-standard, VESA DDC2B |
| | Composite | 3 port, NTSC/PAL-standard, Video signal: 0.7 Vp-p, Sync. signal: 0.3 V |
| | USB | 1 port, USB1.1, 12Mbps, for brilliance control |

2 POWER SUPPLY

12-24 VDC: 1.9-0.9 A

3 ENVIRONMENTAL CONDITION




| | | |
|-----|----------------------|---|
| 3.1 | Ambient temperature | -15°C to +55°C |
| 3.2 | Relative humidity | 93% at +40°C |
| 3.3 | Degree of protection | IP56 (CFR46, front panel), IP22 (chassis) |
| 3.4 | Vibration | IEC60945 Ed.4 |

4 UNIT COLOR

N2.5

FURUNO





| | | |
|----------|----------------|----------------|
| CODE NO. | 001-497-440-00 | 26AN-X-9401 -0 |
| TYPE | CP26-02401 | 1/1 |

| 工事材料表 INSTALLATION MATERIALS | | MU-152 | | | |
|---------------------------------|--|--|-------------------------|-------------|------------------|
| 番号 NO. | 名称 NAME | 略図 OUTLINE | 型名/規格 DESCRIPTIONS | 数量 Q' TY | 用途/備考 REMARKS |
| 1 | Fマウントスポンジ H15 FLUSH MOUNTING SPONGE H 15 |  | 26-005-2123-0 | 2 | |
| | | | CODE NO. 100-351-280-10 | | |
| 2 | Fマウントスポンジ V15 FLUSH MOUNTING SPONGE V 15 |  | 26-005-2124-0 | 2 | |
| | | | CODE NO. 100-351-290-10 | | |
| 3 | コンベックス CABLE TIE |  | CV-125N | 4 | |
| | | | CODE NO. 000-172-164-10 | | |
| 4 | ワッシャー WASHER HEAD SCREW *B* |  | M4X10 SUS304 | 6 | |
| | | | CODE NO. 000-163-836-10 | | |

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO ELECTRIC CO., LTD.

C4497-M01-A



注記

- 1) 指定外の寸法公差は表1による。
- 2) #印寸法は最小サービス空間寸法とする。
- 3) 壁の厚さ(A)は最少10mm、最大20mmとする。

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. #: MINIMUM SERVICE CLEARANCE.
3. BULKHEAD THICKNESS (A): 10≤A≤20.


表2 TABLE 2

| | | |
|----------|--------|--------|
| フード HOOD | B (mm) | D (mm) |
| なし NO | 6 | 364 |
| あり YES | 7 | 368 |

表1 TABLE 1

| | |
|------------------------|----------------------|
| 寸法区分 (mm) DIMENSION | 公差 (mm) TOLERANCE |
| L ≤ 50 | ±1.5 |
| 50 < L ≤ 100 | ±2.5 |
| 100 < L ≤ 500 | ±3 |

型式銘板
NAMEPLATE



FマウントスポンジV15 (2個)
FLUSH MOUNTING SPONGE V15 (2pcs)

FマウントスポンジH15 (2個)
FLUSH MOUNTING SPONGE H15 (2pcs)


剥離紙を剥がして表示部側
ケース裏面のつばに貼付

REMOVE PAPER AND ATTACH THE SPONGE
TO REAR FACE OF BEZEL.

貼付面
ATTACHMENT FACE

付属スポンジの貼付方法
SPONGE ATTACHMENT METHOD






取付穴寸法図
CUTOUT DIMENSIONS



| | | | | |
|----------|-------------|----------------------|---|------------------------------|
| DRAWN | 16/Aug/2017 | I.YAMASAKI | TITLE | MU-152 |
| CHECKED | 16/Aug/2017 | H.MAKI | 名称 | 表示部 (埋込装備S) |
| APPROVED | 16/Aug/2017 | H.MAKI | 外寸図 | |
| SCALE | 1/8 | MASS 4.9 SIZE log | 質量はオプションを含まず MASS DOES NOT INCLUDE OPTION. | MONITOR UNIT (FLUSH MOUNT S) |
| FIG.No. | C4497-601-B | REF.No. | 26-010-100G-3 | OUTLINE DRAWING |

表1 TABLE 1

| 寸法区分 (mm) DIMENSION | 公差 (mm) TOLERANCE |
|------------------------|----------------------|
| L ≤ 50 | ±1.5 |
| 50 < L ≤ 100 | ±2.5 |
| 100 < L ≤ 500 | ±3 |



取付穴寸法
CUTOUT DIMENSIONS

FマウントスポンジV15 (2個)
FLUSH MOUNTING SPONGE V15 (2pcs)

FマウントスポンジH15 (2個)
FLUSH MOUNTING SPONGE H15 (2pcs)

剝離紙を剥がして表示部側
ケース裏面のつばに貼付
REMOVE PAPER AND ATTACH THE SPONGE
TO REAR FACE OF BEZEL.



貼付面
ATTACHMENT FACE

付属スポンジの貼付方法
SPONGE ATTACHMENT METHOD

注 記

- 1) 指定外の寸法公差は表1による。
- 2) #印寸法は最小サービス空間寸法とする。
- 3) 取付用ネジはトラスタネジ呼び径5×20を使用のこと。

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. #: MINIMUM SERVICE CLEARANCE.
3. USE TAPPING SCREWS $\phi 5 \times 20$ FOR FIXING THE UNIT.

| | | |
|----------|-------------|---------------|
| DRAWN | 16/Aug/2017 | I.YAMASAKI |
| CHECKED | 16/Aug/2017 | H.MAKI |
| APPROVED | 16/Aug/2017 | H.MAKI |
| SCALE | 1/8 | MASS 4.9 100g |
| IMG.No. | C4497-603-B | |

| | |
|-----------------|------------------------------|
| TITLE | MU-152 |
| 名称 | 表示部 (埋込装備F) |
| 外寸図 | |
| NAME | MONITOR UNIT (FLUSH MOUNT F) |
| OUTLINE DRAWING | |





表1 TABLE 1

| 寸法区分 (mm) DIMENSION | 公差 (mm) TOLERANCE |
|------------------------|----------------------|
| L ≤ 50 | ±1.5 |
| 50 < L ≤ 100 | ±2.5 |
| 100 < L ≤ 500 | ±3 |




注 記

- 1) 指定外の寸法公差は表 1 による。
- 2) # 印寸法は最小サービス空間寸法とする。
- 3) 取付用ネジはトラスタネジ呼び径 5 × 2.0 を使用のこと。

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. # MINIMUM SERVICE CLEARANCE.
3. USE TAPPING SCREWS φ5x2.0 FOR FIXING THE UNIT.

| | | | |
|----------|------------------------|--|-------------------------------|
| DRAWN | 16/Aug/2017 I.YAMASAKI | TITLE | MU-152 |
| CHECKED | 16/Aug/2017 H.IMAKI | 名称 | 表示部 (卓上装備) |
| APPROVED | 16/Aug/2017 H.IMAKI | 外寸図 | 外寸図 |
| SCALE | 1/8 | 質量はオプションを含みません MASS DOES NOT INCLUDE OPTION | MONITOR UNIT (TABLETOP MOUNT) |
| DWG.No. | C4497-602-B | 図番 REF.No. | 26-010-1100-3 |
| | | | OUTLINE DRAWING |



注記
 *1) 造船所手配。
 *2) オプション。

NOTE
 *1: SHIPYARD SUPPLY.
 *2: OPTION.

| | | | | |
|----------|--------------|-------------|---------------|-------------------------|
| DRAWN | 22/June/2017 | T. YAMASAKI | TITLE | MU-152 |
| CHECKED | 22/June/2017 | H. MAKI | 名称 | 表示部 |
| APPROVED | 23/June/2017 | H. MAKI | 相互結線図 | MONITOR UNIT |
| SCALE | 1/25 | kg | NAME | INTERCONNECTION DIAGRAM |
| DWG No. | C4497-C01-A | REF. No. | 26-010-5001-0 | |

EC Declaration of Conformity



We **FURUNO ELECTRIC CO., LTD.**

(Manufacturer)

9-52 Ashihara-Cho, Nishinomiya City, 662-8580, Hyogo, Japan

(Address)

declare under our sole responsibility that the product

MONITOR UNIT MU-152

(Model name, type number)

to which this declaration relates is in conformity with the following standard(s) or other normative document(s)

IEC 60945 Ed.4.0: 2002 incl. Corr. 1: 2008

IEC 60945 Ed.3.0: 1996, clause 10.3

(title and/or number and date of issue of the standard(s) or other normative document(s))

For assessment, see

- Test Report LIC 12-17-070, LIC 12-17-071, LIC 12-17-072 and LIC 12-17-074, August 31, 2017 prepared by Labotech International Co., Ltd.

This declaration is issued according to the Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility.

On behalf of Furuno Electric Co., Ltd.

Nishinomiya City, Japan
September 14, 2017

(Place and date of issue)

Yoshitaka Shogaki
Department General Manager
Quality Assurance Department

(name and signature or equivalent marking of authorized person)

ECF

(Elemental Chlorine Free)

The paper used in this manual
is elemental chlorine free.

FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-cho,
Nishinomiya, 662-8580, JAPAN

• FURUNO Authorized Distributor/Dealer

All rights reserved. Printed in Japan

A : FEB. 2018

Pub. No. OME-44970-A

(YOTA) MU-152



0 0 0 1 9 4 2 9 3 1 0